

# Checkit Quick-Start Guide

Checkit sensors monitor your assets and trigger an alarm if there are any issues, ensuring that products are kept under the right conditions.

| Link   | Description   |
|--|---|
| <b>Managing alarms</b>                         |   |
| <a href="#">High/low/tripped alarms</a>        | Follow these instructions if you receive high/low alarm, e.g., high temperature, low O2, etc. or a tripped alarm.   |
| <a href="#">Transmitter offline alarms</a>     | Follow these instructions if you receive a transmitter offline alarm.   |
| <a href="#">Transmitter battery low alarms</a> | Follow these instructions if you receive a transmitter battery low alarm.   |
| <a href="#">Probe failure alarms</a>           | Follow these instructions if you receive a probe failure alarm.   |
| <a href="#">WARP/monitoring alarms</a>         | Follow these instructions if you receive the following alarms: <ul style="list-style-type: none"><li>• WARP AC power failure</li><li>• WARP standby battery low</li><li>• Monitoring alarm</li></ul>                              |
| <a href="#">Signal repeater alarms</a>         | Follow these instructions if you receive the following alarms: <ul style="list-style-type: none"><li>• Signal repeater AC power failure</li><li>• Signal repeater standby battery low</li><li>• Signal repeater offline</li></ul> |
| <b>Reports</b>                                 |   |
| <a href="#">Sensor data reports</a>            | Follow these instructions to view, save, and export reports containing sensor data.   |
| <a href="#">Other reports</a>                  | Follow these instructions to view, save, and export reports on incidents, users, setpoints, etc.  |

| Configuration   |  |
|---|--|
| <a href="#">Users</a>   | <p>Users are individuals who have access to the CAM+ Website (cloud portal).</p> <p>Follow these instructions if you want to manage users, e.g., add a user, reactivate a user's password/PIN, modify a user, etc.</p>   |
| <p>Contacts</p> <p><a href="#">Step 1: Create a contact</a></p> <p><a href="#">Step 2: Allocate the contact to a contact list</a></p> | <p>Contacts are individuals we notify in the event of an alarm.</p> <p>Follow the instructions in step 1 if you want to register a contact's details on the CAM+ Website.</p> <p>Follow the instructions in step 2 if you want to allocate the contact to a contact list (a list of individuals who receive alarm notifications at designated times such as during working hours, non-working hours, etc.)</p> |
| <a href="#">Setpoints</a>   | <p>A setpoint is a sensor's acceptable range, including a high and low threshold and an alarm delay period.</p> <p>Follow these instructions to modify a sensor's alarm setpoint.</p>  |
| <a href="#">Isolations</a>  | <p>Isolations are periods during which a sensor's alarms are suspended.</p> <p>Follow these instructions to create an isolation.</p>   |
| Useful links  |  |
| <a href="#">CAM+ Website</a>  | The CAM+ Website is a cloud portal that allows you to view data and reports, complete incident audits triggered by alarms, and configure account settings.   |
| <a href="#">Help Centre</a>   | The Help Centre contains informative articles and how-to guides covering all Checkit hardware and features.  |